

SUMMARY TABLE OF CONTROLS N-COM B601 R SERIES

| | | <i>Tasto</i> | n | ▲ | ▼ | ▲ + ▼ |
|--|---------------------------------------|--------------|-------|-------|-------|-------------|
| Basic Functions | Turning on | | 2 sec | | | |
| | Turning off | | 6 sec | | | |
| | Increase Volume | | | X | | |
| | Decrease Volume | | | | X | |
| Bluetooth Devices | Answer phone call* | | X | X | X | |
| | Voice call | | 2 sec | | | |
| | Speed Dialling Menu** | | X | | X | |
| | Hang up/reject a phone call | | 2 sec | | | |
| | Manual Device Connection | | 2 sec | | | |
| | Phone Conference Activation CHANNEL 1 | | X | | | |
| | Phone Conference Activation CHANNEL 2 | | x2 | | | |
| | Phone Conference Activation CHANNEL 3 | | x3 | | | |
| Turning off the Conference function | | X | | | | |
| Bluetooth Music | Play music (Play) | | | 2 sec | | |
| | Pause Function (Pause) | | | 2 sec | | |
| | Next track (Forward) | | | 4 sec | | |
| | Previous track (REW) | | | | 4 sec | |
| | Share A2DP music | | | 2 sec | | |
| N-Com Intercom (900 / 600 series) | Connection CHANNEL 1 | | X | | | |
| | Disconnection of active intercom | | X | | | |
| | Calling CHANNEL 2 | | x2 | | | |
| | Calling CHANNEL 3 | | x3 | | | |

*Press any key on the N-Com keypad.

**Press the keys at the same time.