

SUMMARY TABLE OF CONTROLS N-COM B902

| | <i>Button</i> | n | on | ▲ | ▼ | ▲ + ▼ |
|------------------------------------|---------------------------------------|-------|-------|-------|-------|-------------|
| Basic Functions | Turning on | | 2 sec | | | |
| | Turning off | | 6 sec | | | |
| | Increase Volume | | | X | | |
| | Decrease Volume | | | | X | |
| | Pairing up Menu*** | | 4 sec | | | |
| | Configuration Menu | | | | | 4 sec |
| Bluetooth Devices | Answer phone call* | X | X | X | X | |
| | Voice call | | 2 sec | | | |
| | Speed Dialling Menu** | X | X | | | |
| | Hang up/reject a phone call | | 2 sec | | | |
| | Manual Device Connection | | 2 sec | | | |
| | Phone Conference Activation CHANNEL 1 | X | | | | |
| | Phone Conference Activation CHANNEL 2 | x2 | | | | |
| | Phone Conference Activation CHANNEL 3 | x3 | | | | |
| | Turning off the Conference function | X | | | | |
| Bluetooth Music / Cable | Play music (Play) | | X | | | |
| | Pause Function (Pause) | | X | | | |
| | Next track (Forward) | | | 2 sec | | |
| | Previous track (REW) | | | | 2 sec | |
| | Share A2DP music | | X | | | |
| | Activate audio via cable | | x3 | | | |
| | Deactivate audio via cable | | x3 | | | |
| N-Com Intercom (900 series) | Connection CHANNEL 1 | X | | | | |
| | Disconnection of active intercom | X | | | | |
| | Calling CHANNEL 2 | x2 | | | | |
| | Calling CHANNEL 3 | x3 | | | | |
| | Group intercom connection | 2 sec | | | | |
| | Group intercom disconnection | X | | | | |
| Radio Menu | Turning on the Radio | | x2 | | | |
| | Turning off the Radio | | x2 | | | |
| | Automatic search for new station | | | 2 sec | | |
| | Change station (pre-set stations) | | | | 2 sec | |
| | Pre-set station | | | | 4 sec | |

*Press any key on the N-Com keypad.

**Press the keys at the same time.

***Starting with the system switched off.