

N-COM B1 SUMMARY TABLE OF CONTROLS

<i>Button</i>		on	on	▲	▲	▼	▼	▲ + ▼	▲ + ▼
<i>Pressure</i>		Brief	Long	Brief	Long	Brief	Long	Brief	Long
Basic Functions	Turning on		X (3s)						
	Turning off		X (4s)						
	Increase Volume			X					
	Decrease Volume					X			
	Activate / Deactivate audio via cable*	X				X			
	Activate intercom	X							
	Deactivate intercom	X							
Bluetooth peripheral	Answer phone call	X		X		X			
	Voice call		X (2s)						
	Hang up/reject a phone call		X (2s)						
	Redial last number							X	
	Mobile phone connection		X (2s)						
	Mobile phone disconnection								X (4s)
	Call transfer								X (4s)
	Activate Conference Mode	X							
Mp3 player	Disconnect A2PD device						X (2s)		
	Play music (Play)				X (2s)				
	Pause Function (Pause)				X (2s)				
	Next track (Forward)				X (4s)				
Setting	Pairing up mode - system turned off		X (4s)						
	Rider-Passenger intercom pair up**	X							
	Erase pair ups**								X (4s)

*Briefly press at the same time.

**With N-Com system in Pairing up Mode.